

Quick Start Guide NCR to HCM to Gateway to BinCloud

So you got a BinMaster system to save your team time, get accurate bulk inventory and, most importantly...avoid ladder climbing. Smart move buster! Now a little early prep will save you and your installer time, hassle and money later on.

Step 1 - Get your team prepared. Address this [EMAIL](#) to your IT, maintenance, electricians, etc.

Step 2 - Provide your installer with the wiring diagram (below) and the [BinDisc guide](#).

Step 3 - When installation is complete, call BinMaster at 402-434-9105, to connect your system with BinCloud software.

